




Installation


Steel trunking 110, 120, 130, 170

110:	120:	130:	170:
STA550004	INS5551000	STA550036	INS5553003
INS5550003	STA550023	INS5552003	STA550121
STA550071	INS5551003	STA550103	INS5553013
STA550013	INS5551002		STA550131
INS5550013	STA550090		STA550055
STA550080			INS5553023
			STA550145






Dismounting




Installation

Steel trunking 165V

STA550045
INS5554003
STA550112




Ref. nr: CSUG3080003




Installation


Steel trunking 183-2, 233-2

INS5555003
INS5558003



Ref. nr. CSUG3080002







Installation



Universal corners

110:	120:	130:	170:
STA550001	STA550174	STA550031	INS5553109
INS5550103	INS5551105	INS5552123	STA550118
STA550068	STA550020	STA550098	INS5553102
STA550010	INS5551101		STA550138
INS5550123	INS5551104		STA550051
STA550077	STA550087		INS5553123
			STA550141





Ref. nr: CSUG3040013

Installation of internal corner



Installation of external corner




Installation

Universal T-piece

120: STA550172
STA550019
INS38050074
STA550086

170: STA550062
INS38051774
STA550151



Ref. nr: CSUG3040012

